

Operation Manual Series W-500



W-510



W-530



W-550

Table of Content

1	Safety information.....	2	6.4	Range	8
1.1	Place of application of the unit	2	6.5	Type of Sensor	8
1.2	Instructions for installation	3	6.6	Unit	9
2	Start-up and adjustment of controller	4	6.7	Language	9
3	General information	4	6.8	Systeminfo	9
4	Control Panel	5	7	Controller On / Off.....	9
4.1	Overview of Functions.....	5	8	Troubleshooting.....	10
4.2	Standard Display Information	5	9	Terminal connections	11
4.3	Status LED.....	5	10	Connector pin assignment	12
4.4	Fault Detection	6	11	Technical Data.....	13
5	Set-up Menu	7	12	Repair and Maintenance.....	14
5.1	Adjustment of Set-Point	7	13	Disassembly and Disposal	14
6	Settings Menu.....	7	14	Drilling template	15
6.1	Structure of Menu:	8	15	Declaration of Conformity	16
6.2	Setpoint	8			
6.3	Lower / Upper limits.....	8			

1 Safety information



Before putting the unit into operation, the safety information, the instructions for installation and the operating manual that is supplied with the unit must be read and observed.

Please read the safety information carefully and comply with the items stated. This is a matter of safety for personnel and equipment. The unit is predominantly designed as a temperature controller for electrical heating systems. Improper application, installation, configuration or operation of a system or that which goes against the machine's intended purpose may cause severe personal injuries and extensive property damage!



Important: This unit is not a safety temperature limiter according to DIN EN 60730-1

The unit must not be installed in potentially explosive atmospheres. If a process function originating from an explosion-risk area is to be processed by the unit installed outside the explosion-risk area, all supply lines of the unit leading into the explosion-risk area must be guided via safety barriers!

The prerequisite for error-free and safe operation of the unit is its careful transport and storage, as well as correct assembly and installation. This device may only be installed, configured, parameterized and commissioned by qualified persons who are familiar with installation, commissioning and maintenance of comparable devices and with the system in which the device will be applied and who have appropriate knowledge in the field of instrumentation and control. Operating staff of the system in which the device is to be used must be instructed on operation and control of the unit by qualified persons.

Please observe and comply with:

- The contents of the present manual for installation and operation of the unit, in particular the information on installation, taking into operation, any notes in bold print and adjustment of the device to suit the overall system.
- Any and all safety information attached to the unit
- Any and all relevant safety regulations for installation and operation of electrical systems
- The keeping of this manual in a safe place for future use.

The regulations stated in the present manual are applicable and valid in all EU countries. For use of the device outside of an EU country, the relevant national rules and regulations must be considered.

This device has been produced and tested in accordance with DIN EN 61010 Part 1, "Safety requirements for electrical equipment for measurement", and has left our company in an error-free condition in terms of its safety and functionality.

1.1 Place of application of the unit

The unit is designed as a temperature controller for flexible application in electrical heating systems. The place of operation or installation of the temperature controller must not be close to motors,

transformers, circuit breakers or other inductive loads, it must be shock-free and vibration-free and positioned on solid ground. The ambient temperature at the place of installation must be between -20°C and 50°C , with a relative humidity of $< 90\%$ (noncondensing). Aggressive and corrosive gases and vapors may damage the unit.

1.2 Instructions for installation

Please read the installation instructions carefully and comply with all conditions mentioned here during installation of the unit. In case of non-compliance with the Instructions for installation, faults or malfunctions may occur, or the unit may fail to comply with the required EMC guidelines and the conditions for CE-conformity will not be fulfilled.

Before connection of the unit and before putting it into operation, please ensure that the operating voltage and the conditions for the operating voltage required by the unit correspond to the conditions on site (cf. name plate and technical specifications). If required, take any appropriate measures.

Please make sure that the control and load voltage on site are switched off and secured against accidental reactivation during installation of the device. The electrical connections must be made on the basis of the connection diagram and the relevant national rules and regulations. The supply lines for the device must be laid such that they are free from any tensile loads and are not exposed to risks of shearing or crushing under any circumstances.

The mains connection and the connections for the loads must each be provided by suitable cables with a cross-section of a minimum of 1.5mm^2 .

For sensor lines and signal lines, it is highly recommended to use shielded cables (especially if lines are long and/or running along potential sources of interference); for thermocouples, shielded compensation lines should be used likewise. Sensor lines and signal lines must be installed such that they are spatially separated from the load and control lines (high-voltage lines). If signs of incorrect switching behavior are detected the circuit must be put out of service until remedial action.

For intermediate clamping of compensation lines for thermocouples, no regular terminals may be used, since this would result in generation of additional thermocouples that may falsify the measuring results.

Connect the shield of the sensor lines and the signal lines with the signal ground as close to the unit as possible and lay a line with a diameter of minimum 1.5mm^2 from this point to the PE bus bar along the shortest possible route.

Any inductive loads activated by the unit, such as contactors, valves, motors, transformers, etc. must be wired separately and interferences must be prevented using device-specific suppression devices.

For connection on „Line10A Fuse int. “, the load circuit is fused against excess current by means of an internal miniature fuse. For connection on „Line unfused“, the load circuit must be protected against excess current by means of a suitable external fuse. (See Chapter 9, page 11)

The present manual does not contain all notes for regulations, standards, etc. that must be observed and complied with during working with the unit in connection with systems and plants. Any such

regulations, standards, etc. shall be complied with and observed by the operator of the unit with regard to specific requirements of the respective system or plant.

2 Start-up and adjustment of controller

The unit is delivered with a default setup. This Setup mostly will not fit to the application. The controller has to be set to the application-specific temperature limits and sensor type.

Power-on



Carefully inspect the wiring and connections once again.

Incorrect wiring or connection of the unit may cause severe damage of the unit and the plant. Please make sure that during initial switch-on of the unit the load voltage of the plant is switched off since the unit will not yet have been adjusted to the plant and may possibly trigger faults or malfunctions.

Now, switch on the operating voltage of the unit.

Setup

Enter the Setup menu and set the Values for lower / upper limit and range. Choose the desired temperature sensor. See also chapter 5 Set-up Menu on page 7

3 General information

The W-500 is a compact, feature rich, intuitive FAT Temperature Controller for wall-mounting. FAT stands for Fast-Adaptive-Tuning. A novel algorithm permanently adjusts the control parameters to the control process. The common adjustment of PID controllers or the execution of an auto tuning procedure is obsolete.


The self-optimizing controller logic leads to an efficient adaption to any closed-loop controlled pass and quickly reaching adjustment between set-point temperature and actual (temperature) value.

All functions are easily accessible via the text menu display and can be easily reached and set via the buttons on the control panel.








The W-500 is equipped with a long-life Hybrid-Relay designed for low thermal losses inside the housing. An additional Shutdown-Relay underlines the high standard in terms of safety and efficiency of the W-500.

A multi-colored LED is signaling the different operating modes, easy viewable in the distance. Electronics are protected against overcurrent and high thermal load.





4 Control Panel



4.1 Overview of Functions

- Enter set up menu: simultaneous pressing Enter Button  and Back Button 
- Change Set-Point Temperature: Long press Up  or Down  Button
- Failure notes can be reset by pressing enter button 
- Controller On/ Off: simultaneous pressing Up Button  and Down Button  for several seconds

4.2 Standard Display Information

- Set-point temperature: Temperature setting maintained by the controller
- Actual (temperature) value: Actual temperature measured by connected temperature sensor
- Thermometer Icon: Temperature above  / beneath  / in-between  range of tolerance at set-point temperature
- Heater-Icon  visible: Heater on

4.3 Status LED

Starting procedure:



After connecting to power supply, the controller starts with a self-test: white LED on for 1 sec.

Self-test successfully completed and controller starts heating: green LED on for 0.3 sec.

If a failure would be detected a default signal will show up: see 4.4 Fault Detection.

Heat-up phase:



Usually, after startup, the temperature is below the set point and the signal LED flashes slowly (1 Hz) blue. This means set point is not reached yet.


Set-point temperature reached:



The Controller works at set-point temperature inside the tolerance-band set by the user: green LED permanent on

Temperature monitor:

The temperature is during operation permanently under control. The LED remains green at set-point temperature in-between the band of tolerance. Above and below this temperature range the LED starts to blink with a frequency of 1Hz. Blue signals too low and red too high temperatures.



4.4 Fault Detection

From start and during operation the controller is permanently checking the following Failure:


1. PCB temperature
2. power supply
3. sensor break
4. failure of the switch.

Signal LED on failure

If any failure occurs the controller stops heating (stand-by) and the Signal LED starts fast blinking with a frequency of 4 Hz.

1. Device failure:  4 Hz
2. Sensor failure: 




Display on failure

Additionally, the error is shown in the display. Failure notes can be reset by pressing enter button . If the failure note cannot be reset by this procedure, the occurring problem has to be solved and the controller reconnected to power supply to restart the controller.

Please also see chapter 8 Troubleshooting on page 10.



5 Set-up Menu


5.1 Adjustment of Set-Point


To get from normal operation directly to Set Point adjustment, just long-press the button ,  or .

Display:





Pressing Up  or Down  buttons to change value between lower and upper limit. These limits also can be set by the user. (see chapter **Fehler! Verweisquelle konnte nicht gefunden werden.**, page **Fehler! Textmarke nicht definiert.**)

Enter Button  : Confirmation of chosen set point temperature



Back Button  : Abort, so the setpoint stays unchanged.


6 Settings Menu


Enter set-up menu by simultaneously pressing Enter Button  and Back Button . All settings can be adjusted in the menu.

Display:




Pressing Up  or Down  Buttons to navigate through the menu.

To enter a menu item, press the Enter Button .

To leave any menu item, press the Back Button .

6.1 Structure of Menu:



6.2 Setpoint

See 5.1

6.3 Lower / Upper limits

Limits for minimum and maximum temperature values of the set-point adjustment. Adjust these values according to the process environment. This avoids accidentally wrong setting of setpoint values according to used heater.

6.4 Range


Current actual temperatures inside the Range are considered balanced to the set-point value, signaled by the green LED-light on and the symbol ✓↓ on the display. Range settings between $\pm 0,5\text{ }^{\circ}\text{C}$ and $\pm 20\text{ }^{\circ}\text{C}$. Step width is $0.1\text{ }^{\circ}\text{C}$


6.5 Type of Sensor

6.5.1 Auto detection

The auto detection recognizes the following sensors:

- PT100 (2-, 3- or 4-wires)
- PT1000 (2-, 3- or 4-wires)
- Thermocouple (Type K)

The Auto detection can be started by pressing enter  inside the sensor menu.


The found sensor type has to be confirmed by pressing enter  again.

Back  can abort the process of detection and parameters stay unchanged.



All other types of sensors have to be chosen manually.

6.5.2 Manual selection of sensor

A List of all sensors will show up. Select desired sensor type out of list and confirm by pressing enter .

6.6 Unit

Selection between degree Celsius and degree Fahrenheit

6.7 Language

Languages available: German, English, Spanish, French and Japanese.

Hint: In every language the language menu and the languages are always labeled in English as well.



This helps finding the language menu in every language.

6.8 Systeminfo






Information about the product: firmware and hardware version

7 Controller On / Off

The controller switches automatically on with the power supply connected.


By simultaneously long pressing  and  the controller goes to standby or can be powered on again.

8 Troubleshooting

Error:	Actions:
Display stays off	<ul style="list-style-type: none"> • Check power supply • press  and  together for a few seconds to power on. • Disconnect and reconnect controller from mains supply. • Contact Service.
Message „sensor failure“	<ul style="list-style-type: none"> • Press  and  together to enter menu and check sensor settings (correct sensor type selected?) • Check wiring for short circuit or wire breaks, correct connection in Terminal / Plug • Check resistance value of Sensor. • Replace Sensor.
Message „controller overheated!“	<ul style="list-style-type: none"> • Press  to acknowledge error or disconnect controller from mains supply and let cool down. Then reconnect. • Check correct connection in terminals for mains supply and heater connection. • Provide better air circulation. • Check current in Heater circuit.
Message „AC line error!“	<ul style="list-style-type: none"> • Disconnect and reconnect controller from mains supply. • Are stable 50Hz or 60Hz available? • Power off sources of noise on mains supply like big motors or power converters. • Install suitable noise suppression measures. • Used on mobile power generator? Check voltage and Frequency. Choose suitable supply. Test on local power grid. Message still appears? Contact service.
Message „system fault“	<ul style="list-style-type: none"> • Disconnect and reconnect controller from mains supply. • Message still appears? Contact service. • Message does not appear? Check all settings and readjust if necessary.
Message „heater/switch broken!“	<ul style="list-style-type: none"> • Check wiring of heater circuit • Check heater for short circuit or wire break. • Power of heater too low? Less than 5W? • Disconnect and reconnect controller from mains supply. • Message still appears? Contact Service.
Message „switch broken!“	<ul style="list-style-type: none"> • Malfunction of shutdown relay. • Disconnect and reconnect controller from mains supply. • Message still appears? Contact Service.

Service mail: service@winkler.eu

9 Terminal connections



K1: Power supply and Heater:




- Line unfused: Clamp for phase; power supply for currents >10 A or >2300 W at 230 VAC / 1100 W at 110 VAC. **Protection against overload and over-currents has to be secured by external fuse!**
- Line 10 A Fuse int.: Clamp for phase; power supply for currents <10 A or <2300 W at 230 VAC / 1100 W at 110 VAC. Fix mounted fuse inside controller.
- N: Clamp for neutral conductor of power supply
- N Heat: Clamp for neutral conductor of heater
- L Heat: Clamp for phase of heater

K2: Thermocouples (*Polarity!*)

K3: Resistance temperature sensors. (Pt100/1000, Nickel120, NTC10k/100k, etc.)

- 2-wire sensor, clamps K3.1 and K3.4
- 3-wire sensor, clamps K3.1, K3.2 and K3.4
- 4-wire sensor, clamps K3.1, K3.2, K3.3 and K3.4

Wiring-Scheme for K3:




K4: Potential-free signal for external monitoring or control systems

Earth Connection: Screw thread for earth connection of controller and heater (cable lug supplied)

10 Connector pin assignment


Amphenol ecomate C016 6+PE



Heater (max. 10 A) protected with internal fuse

Pin	Function
1	L Heater
2	N Heater
3	not connected
4	not connected
5	Sensor Controller +
6	Sensor Controller -
PE	Earth connection

Binder Series 694 4+PE



Heater circuit (max 16A) must be protected by external fuse (e. g. circuit breaker)

Pin	Function
1	L Heater
2	N Heater
3	Sensor Controller+
4	Sensor Controller -
PE	Earth connection

11 Technical Data

W-510	Max. Current Sensors Connection	16 A selectable (W-510S) Connection via cable glands (2 × M12 + 2 × M16)
W-530	Max. Current Sensors Connection	10 A Choice of resistance-based sensors (W-530R) or thermocouples (W-530T) Mains connection via 1.5 m H05VVF cable with Schuko plug (CEE 7/7) Heater connection via round socket Amphenol ecomate C016 6+PE
W-550	Max. Current Sensors Connection	16 A Choice of resistance-based sensors (W-550R) or thermocouples (W-550T) Mains connection via 1.5 m H05VVF cable with Schuko plug (CEE 7/7) Heater connection via round socket Binder series 694 4+PE
Nominal voltage		90...260 VAC 50/60 Hz
Output Current		Max. 16 A (up to 10 A possible over internal fuse)
Power switch		Hybrid Relay (> 2.5 Mio. switching cycles specified)
Switching cycles		> 2.5 million
Shutdown-relay		breaks heating circuit on failure (single-pole)
Sensor inputs		Pt100, Pt1000, Nickel 120 (2, 3 or 4-wire) NTC 10k, NTC 100k (2, 3 or 4-wire) Thermocouples K, J, E or N all inputs potential-free with sensor break detection
Adjustment range		Pt100, Pt1000: -120 °C ... +850 °C Ni120: -50 °C ... +250 °C NTC: -20 °C ... +250 °C K Thermo.: -200 °C ... +1350 °C J Thermo.: -210 °C ... +1200 °C E Thermo.: -200 °C ... +1000 °C N Thermo.: -200 °C ... +1300 °C
Controller Type		FAT (Fast-Adaptive-Tuning)
Thermal Protection		+85 °C (Electronic Temperature, resettable)
Housing		W-510, W-530 : 151 x 125 x 60 mm W-550 : 151 x 125 x 90 mm Polycarbonate with non-detachable clear cover UL 94-V0 Hinges for manual operation → No tools required!
Display		LCD graphic display
Status LED		3-coloured LED for signaling of operation conditions
Operation		via keypad and multilingual menu control optional: via WRZF310N control unit (distance up to 7m)
Languages		English, German, Spanish, French, Japanese
Potential-Free Signal output		50 mA max. 45 V (potential-free) switch closed, if temperature is within range (Status LED green)

Ambient temperature	-20 °C ... +50 °C
Relative humidity	< 90 % noncondensing
Protection Standard	IP65 (cover closed)
Protection class	1
Weight	0,5 kg (unit with cable glands) 0,7 kg (unit with output socket)

12 Repair and Maintenance

If the controller is damaged, please return the controller to us with an error description.

Maintenance intervals and Maintenance directives according to DGVU Rule 3 apply.

If the device is dirty, turn power off, and clean it with a damp cloth. Heavy dirt may be cleaned with a non-abrasive, solvent-free cleaning agent.

13 Disassembly and Disposal



The device may only be disassembled when it is switched off, disconnected from the mains and secured!




Electronic devices are recyclables and do not belong in the household waste! Dispose of the product at the end of its service life in accordance with applicable legislation.

14 Drilling template





Important: Leave at least 50mm / 2in of free space around the controller for easy cover opening and air ventilation.

Check the scale after printing for correct size, for correct drilling positions



Check printing scale 1:1



15 Declaration of Conformity

EU-DECLARATION OF CONFORMITY

winkler.eu



Manufacturer: Winkler AG
Englerstr. 24
69126 Heidelberg

Contact: Tel.: +49 6221 3646-0
Fax.: +49 6221 3646-40
sales@winkler.eu
www.winkler.eu

Product group: Temperature controllers

Series / item: **Series W-500 / WRW5...**

Directives: Directive 2014/35/EU Low Voltage Directive
Directive 2014/30/EU Electromagnetic Compatibility
Directive 2011/65/EU restriction of the use of certain hazardous
substances in electrical and electronic
equipment
Directive 2017/2102/EU amending Directive 2011/65/EU

We hereby declare that in planning and manufacturing of this product the basic safety and health requirements of the EU Directives mentioned above have been observed.

Further rules and technical specifications applied:

EMC requirements: EN 61326-1:2013
Emission: EN 61000-6-4:2011
Immunity: EN 61000-6-2:2006
Safety requirements: EN 61010-1:2011

Any modification to the product without our consent will make this declaration invalid.

Heidelberg, April 17th, 2019

Winkler AG

A blue ink signature of CEO A. Zenner, consisting of several fluid, overlapping strokes.

CEO A. Zenner